

Dulux[®]

Dulux Professional SteriGuard Ultra

Professional
SteriGuard[®]

Contact us on 13 23 77
dulux.com.au/specifier
dulux.com.au/trade
dulux.com.au/steriguard



Background

Dulux Professional® SteriGuard® Ultra is a two part durable polyurethane that when mixed, uses Bayhydrol® Water Based Technology from Bayer MaterialScience to produce an ultra tough, chemical resistant interior finish designed to withstand high intensity cleaning cycles in clinical environments. The low VOC[†], low odour formula ensures quick return to service with less disruption. Dulux Professional SteriGuard Ultra contains Bio-Pruf™ Technology, allowing it to withstand clinical cleaning cycles, therefore assisting in the protection against mould and bacteria, helping to keep surface clean and help maintain good interior air quality. All Dulux Professional products are designed to meet the application needs of painters.

Features

Bio-Pruf™ Technology → A specially developed biocide that protects against mould and bacteria when used in conjunction with clinical cleaning programmes.



Ultra hard wearing → Withstands high intensity clinical cleaning cycles with cleaning agents typically used in such environments. This is an important consideration for facility managers and asset owners when considering ongoing maintenance. The Bayhydrol Water Based Technology helps to achieve this ultra tough, chemical resistant, specialty coating.

Low odour, low VOC formula → Allows for the facility to return to service quickly and is important for both patient and applicator comfort. This also assists in the maintenance of good interior air quality.

Where to use?

Ideal for broadwall areas in high intensity clinical environments such as trauma bays, emergency rooms and procedure rooms, intensive care, and laboratories in such environments as hospitals, veterinary and dentist practices, prisons, aged care, medical centres, gym and sports facilities. High intensity clinical cleaning cycles use harsh cleaning agents such as chlorine agents, quaternary ammonium agents, disinfecting wipes, low level biocides and benzalkonium chloride on a frequent basis.

Application details

1. Mix the contents of Part A and Part B together thoroughly by hand using a paddle stirrer. Allow to stand for 5 minutes. Please pour ALL of Part B into Part A. Do not part mix.
2. Apply one coat of Dulux Professional SteriGuard Ultra. If paint is left over and still within pot life, apply second coat* or apply second coat after overnight dry with a new kit.
3. Use a brush or synthetic roller (Clear – short nap length, White – medium nap length).

Product Description

	Line Shade	Size
Dulux Professional SteriGuard Ultra Part A White	56U 84179	3L
Dulux Professional SteriGuard Ultra Part A Clear	56U D0065	3L
Dulux Professional SteriGuard Ultra Part B Hardener	56X D0100	0.75L

[†] Low VOC formula – Dulux Professional SteriGuard Ultra, when mixed (Part A and Part B) contains less than 5g per litre of VOCs. VOCs (Volatile Organic Compounds) contribute to atmospheric pollution.

* Please note that thinning is not usually required, but product can be thinned with up to 50ml of water per litre if necessary (prior to applying second coat).

© Dulux, worth doing, worth Dulux, Professional and SteriGuard are registered trademarks of DuluxGroup Australia Pty Ltd. Bio-Pruf is a registered trademark of Dow Chemical, Bayhydrol is a registered trademark of Bayer.

4. Please note that the product cannot be used beyond the pot life. This will compromise the application and final appearance of the product on the wall as well as its performance properties.

Drying times on a day of around 25°C and 50% humidity:

Touch Dry: 1 hour

Re-coat: 1.5 hours

Note: Under cooler or humid conditions allow longer times. Ensure temperature is above 10°C during application and drying

FAQs

What are the gloss levels?

White: Gloss Level 4–10 at a 60 degree viewing angle (Low Sheen).

Clear: Gloss Level 7–12 at a 60 degree viewing angle (Low Sheen).

Is the product tintable?

Yes, the white base is tintable with Decorama tinters. Maximum tinter 2Y/L. Available in any Dulux colour tinted from a white base. Please remember to tint Part A only. Clear is not tintable.

How many coats do I require?

The product requires two coats as mentioned above, however some colours may require more than two coats, especially when painting over dark colours.

Can I spray this product?

This product is not to be sprayed (contains isocyanate).

When brushing and rolling this product appropriate PPE (Personal Protective Equipment) should always be worn. This includes safety glasses, impervious gloves and overalls as a minimum. Refer to the product Safety Data Sheet for full information.

What is the pot life of this product?

The pot life of SteriGuard Ultra is 2 hours at 25°C (3.75L mixed volume).

Contact

Phone 13 23 77

Email dulux.customer.service@dulux.com.au
dulux.com.au/trade
dulux.com.au/specifier
dulux.com.au/steriguard